

©2023 BabylissPro

Distributed by:

Dateline Imports P/L

Professional Products Division Banksmeadow, NSW 2019 Australia

Ph: 61 2 9666 3611

www.babylisspro.com.au

Dateline Imports NZ Ltd

66 Apollo Drive Albany, Auckland NZ 0632

Ph: 64 9 415 5415

www.babylisspro.co.nz



Model BNTMCS75BKA - 19mm (¾") BNTMCS125BKA - 32mm (1¼")

For your safety and continued enjoyment of this product, always read the instruction book carefully before use.


BABYLISS PRO MIRACURL PRO IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions are required to always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY CAUTIONS

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- WARNING Do not use this appliance near bathtubs, showers, basins or other containing water.



- Take care to avoid contact between the hot surface of the barrel and the skin of the face and neck.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
- When the appliance is connected to the power supply, never leave it unattended.
- Always place the appliance with the stand, if any, on a heat-resistant, stable flat surface.
- Do not play with the appliance, it is not a toy.
- Burn hazard. Keep appliance out of reach from young children, particularly

- during use and cool down.
- Always place the appliance with the stand, if any, on a heat-resistant, stable flat surface.
- Do not place the hot curling iron on any heat sensitive surface and always allow to cool before storing away.
- When storing the unit make sure it is unplugged and do not wind the supply cord around the curling iron.
- This appliance should not be used on, by or near children or individuals with certain disabilities.
- · Store out of children's reach.
- Do not use the appliance if the cord is damaged. In the event of damage discontinue use immediately. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or similarly qualified persons in order to avoid a hazard.
- Return the appliance to the nearest service facility for examination, electrical or mechanical adjustment or repair.
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- For additional protection, the installation of residual current device (RCD) with a rated operating current not exceeding 30mA is available in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Do not use the appliance if it has been dropped or if it shows noticeable damage.
- Do not leave unattended when switched on and always allow to cool before storing away.
- Do not use any attachments other than those recommended by BabylissPRO.

Keep the appliance dry

OPERATING INSTRUCTIONS

This appliance is intended for professional use. Use on Alternating Current (50-60Hz) only. Standard appliances are designed to operate at 120-240 volts AC.

DUAL VOLTAGE

This styler has dual voltage. It will automatically adjust to the proper voltage. Use an adapter plug (not included) with correct configuration, prior to use in outlet.

NOTE: Do not use this styling appliance on hair extensions.

FEATURES

NANO TITANIUM

Your Nano Titanium MiraCurlPRO has many benefits. Nano titanium is an exceptional conductor of heat and is stable in ultrahigh temperatures. The Nano Titanium technology utilizes micro particles of titanium and ceramic, providing the ultimate benefits for beautiful, healthy-looking hair. Nano titanium yields maximum far-infrared heat, penetrating the hair from within for gentle styling without damaging hair. Nano titanium emits natural ions for faster stying, locking in hair's own natural moisture. This Nano Titanium styler will give your hair a smooth, silky shine while eliminating frizz.

NO-TANGLE FEATURE

MiraCurlPRO is safe and easy to use when used properly. However, should improper use occur, the anti-tangle feature has been designed to immediately stop drawing the hair in and will reverse to a neutral position.

IMPORTANT: If hair does get tangled, unplug the unit and gently work the hair out of the unit. Take very small strands, one at a time, and slowly remove from the chamber. If hair is tight around the barrel, carefully and

gently loosen hair outside of the tool with your fingers, removing small sections at a time. Make sure fingers do not come in contact with heated chamber.

AUTO BEEP INDICATOR

Unit will beep when curl is ready to release.

MEMORY SETTING

Unit will default to previous settings used for quick styling.

AUTO SHUTOFF

If the appliance is switched on for more than 60 minutes continuously, it will automatically switch off. If you wish to continue using the appliance, simply press the On/Off button to turn the power on. It will default to the last settings used.



STEP 1

Be sure the removable sleeve is in the lock position. This will align the internal curling chamber to the sleeve openings. Make sure the shorter opening of the sleeve is facing the client's head.



STEP 2

Hold the MiraCurlPRO in the vertical position. Slide through a section of hair no more than 4cm (1.5") wide until the hair passes the

-

-

indicated mark and press the activation button. Hair will be automatically drawn into the curl chamber.



STEP 3

Depending on the curl type selected (tight, soft or loose), the MiraCurlPRO will start counting when the activation button is pressed and will beep at regular intervals as the curl is being formed. The machine will signal 4 beeps in quick succession when the timing is complete. Slowly pull the MiraCurlPRO downwards to release the curl.



FAST, EASY, VERSATILE.

The MiraCurlPRO delivers fabulous, luminous curls effortlessly. This new, advanced automatic curler is extremely lightweight and ergonomic, delivering consistent curls each and every time. The final results are endless depending on the type of hair, selected curl direction, selected curl type and styling techniques

USER MAINTENANCE

Your styler is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool. Twist off cover and wipe curl chamber and cover with a soft damp cloth. Replace cover back on unit after dried. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

VANISHING LED DISPLAY

Offers intuitive setting selection.

60-SECOND HEAT-UP

NOTE: Curl chamber will be hot to the touch.

GET TO KNOW YOUR PROFESSIONAL STYLER

Models

BNTMCS75BKA - 19mm (¾") BNTMCS125BKA - 32mm (1¼")



TWO YEAR WARRANTY

The warranty may only be claimed where proof of original purchase is presented, i.e. original purchase receipt or invoice. We recommend attaching a copy of your purchase receipt to this instruction book and storing in a safe place.

To make a warranty claim you can return the defective product back to the place it was purchased where it will be replaced, exchanged or repaired (see point 12 in conditions).

Trade purchasers who have purchased from us directly should contact us directly with regard to warranty claims.

Please have the following details to hand:

- 1. Date of purchase
- 2. Details of where the product was purchased
- 3. Product Name/Model Number
- 4. Confirm you have your purchase receipt
- 5. Detail the problem with your product

It is important to retain your proof of purchase. We recommend attaching your receipt to this page.

For advice with regard to the warranty claim process please contact Customer Services:

Dateline Imports P/L Professional Products Division

Banksmeadow, NSW 2019 Australia

Ph: 61 2 9666 3611

www.babylisspro.com.au

Dateline Imports NZ Ltd

66 Apollo Drive Albany, Auckland NZ 0632

Ph: 64 9 415 5415

www.babylisspro.co.nz

WARRANTY AGAINST DEFECTS

A. AUSTRALIAN CONSUMER LAW

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. 2. The quarantees under the Australian Consumer Law ("ACL") are provided in sections 51 to 59 inclusive of the ACL ("Statutory Guarantees") and the remedies are provided in sections 259 to 266 inclusive of the ACL ("Statutory Remedies").

In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

B. BabylissPRO EXTENDED WARRANTY

1. In addition and subject to the Statutory Guarantees and Statutory Remedies, the following express warranty ("Warranty") commences from the date of purchase and continues for a period of 24 months ("Warranty Period") after which it expires. Subject to the conditions in Section C below, Dateline warrants to the original purchaser ("Purchaser") of the BabylissPRO product that is the subject of this warranty ("Product") that if during the Warranty Period, the Product suffers from any defect caused by faults in materials or workmanship. Dateline will a) replace the Product, or b) exchange defective part in the Product or c) repair the Product, as Dateline may choose in its discretion

- ("Warranty"). In this Warranty "Dateline" means Dateline Imports P/L (ABN 60 000 557 282) of Banksmeadow, NSW 2019, Australia.
- To honour the Warranty, Dateline must replace, or exchange parts in, or repair, the Product, as Dateline determines, in accordance with paragraph B1 above, subject always to the conditions in Section C below.
- If any of the conditions in Section C below are inconsistent with any provisions of the ACL or regulations made there under, those provisions of the ACL or regulations shall prevail to the extent of the inconsistency.

C. CONDITIONS

- The Product must be used in accordance with manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Product be attributable to misuse, abuse, accident, act of God such as lightning, or nonobservance of manufacturer's instructions on the part of the user. This Warranty does not cover ordinary wear and tear in the Product or its parts.
- Dateline does not accept liability for a) any loss or damage however suffered, caused by or arising out of any failure to use the Product in accordance with the manufacturer's instructions, and b) any indirect, consequential or economic loss or damage however caused.
- This Warranty is immediately void if a) any serial number or appliance plate is removed or defaced, b) the Product has been serviced or otherwise repaired by a person not authorized to do so

- by Dateline or where non approved replacement parts are used.
- 4. The Product must be connected to the electrical voltage supply as specified in the ratings label located on the Product. This Warranty does not cover defects arising from incorrect voltage supply.
- This Warranty may only be claimed against where proof of original purchase is presented, for example, original receipt or invoice.
- 6. Any parts of the Product that need to be replaced, or if the whole Product needs to be replaced, the replaced Product, become the property of Dateline. The Warranty on any replacement Product or parts will expire on the same date that the Warranty Period on the original Product expires.
- 7. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Product which the Purchaser has under the ACL, and applicable laws in New Zealand, which rights and remedies by law may not be excluded. All other warranties and representations express and implied are hereby excluded.
- The defect must have occurred during the Warranty Period and Purchaser bears the onus of proving that fact, and that the defect was not caused by any of the causes excluded from this Warranty.
- This Warranty does not cover Products purchased from any person who is not a retailer serviced by Dateline Imports P/L or purchased second hand.
- The Purchaser is responsible for all postage and freight charges and any other expenses incidental to claiming against this Warranty.

- The Warranty excludes consumable items (such as blades or brushes) and normal wear and tear.
- 12. If you're certain your product is defective, and the product is covered by the terms of this warranty, you need to take the product back to the place you purchased it from, where the retailer will replace the product for you, exchange defective parts, repair the Product or refund at Dateline's discretion. In this event, per the terms of this warranty you will need to present this portion of the warranty information and the purchase receipt as proof of purchase so please make sure you keep both these instructions and your receipt on hand for the duration of the warranty period.

6 7