

©2021 BabylissPro

Distributed by:

Dateline Imports P/L
Professional Products Division
Banksmeadow, NSW 2019
Australia

Ph: 61 2 9666 3611
www.babylisspro.com.au

Dateline Imports NZ Ltd
66 Apollo Drive
Albany, Auckland
NZ 0632
Ph: 64 9 415 5415

IB-20/365

BabylissPro®



**PROFESSIONAL
CERAMIC CURLING IRON**
Model BAB2264DA (25mm)

For your safety and continued enjoyment
of this product, always read the
instruction book carefully before use.

BaBylissPRO Instant Heat PROFESSIONAL CERAMIC CURLING IRON

When using electrical appliances, especially when children are present, basic safety precautions are required to always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY CAUTIONS

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not immerse into water or other liquids. Do not use near basins or other vessels containing water.
- Do not immerse the appliance in water or other liquids.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Take care to avoid contact between the hot surface of the barrel and the skin of the face and neck.
- Do not play with the appliance, it is not a toy.
- Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down.
- Always place the appliance with the stand, if any, on a heat-resistant, stable flat surface.
- Do not place the hot curling iron on any heat sensitive surface and always allow



- to cool before storing away.
- When storing the unit make sure it is unplugged and do not wind the supply cord around the curling iron.
- This appliance should not be used on, by or near children or individuals with certain disabilities.
- Store out of children's reach.
- **Do not use the appliance if the cord is damaged. In the event of damage discontinue use immediately. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or similarly qualified persons in order to avoid a hazard.**
- Return the appliance to the nearest service facility for examination, electrical or mechanical adjustment or repair.
- Always ensure that the voltage to be used corresponds to the voltage marked on the unit.
- For additional protection, the installation of residual current device (RCD) with a rated operating current not exceeding 30mA is available in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Do not use the appliance if it has been dropped or if it shows noticeable damage.
- Do not leave unattended when switched on and always allow to cool before storing away.
- Do not use any attachments other than those recommended by BabyLissPRO.

Keep the appliance dry

OPERATING INSTRUCTIONS

This appliance is intended for professional use. Use on Alternating Current (50Hz) only. Standard appliances are designed to operate at 240 volts AC.

FEATURES:

This curling iron is available in 25mm diameters. The 25 temperature settings and fast heat technology combine to provide styling versatility for all hair textures.

TEMPERATURE SETTING GUIDE

Temp. Setting	Hair Type
<i>Low: 1- 8</i>	Delicate, thin, easy to curl hair
<i>Med.: 9-17</i>	Normal to treated hair
<i>High: 18-25</i>	Thick or wavy hair

NOTE: The red and green indicator lights will flash until the required temperature is reached

CLEANING & MAINTENANCE

The appliance may require cleaning due to a build up of residue from hair products.

To clean:

- Ensure the appliance is switched off, unplugged and cool.
- Using a damp cloth and mild detergent or soap, wipe the appliance. Ensure the appliance has dried thoroughly before re-using.

IMPORTANT: Do not immerse the appliance in water or other liquids.

CURLING IRON BASICS

1. Plug the appliance into a standard electrical outlet (240V).
2. Turn the temperature regulator dial to the setting that is appropriate for your hair type. The iron will heat up very quickly.
3. Section hair evenly, and comb each section before winding. Place curling iron midway up the hair section; then spread hair evenly between tongue and barrel. To avoid crimped ends, make sure they are securely wound under the clamp in the direction of the desired curl.

4. Wind the hair up as far as you want it curled, being careful not to let the iron touch the scalp. Hold in place for 8-12 seconds. For looser, free-flowing curls, roll more hair. For tighter, bouncier curls, roll less hair.
5. To remove curling iron, unwind the hair. To "set" the curl, do not comb or brush hair until it cools.
6. Some experimenting is necessary when first using the curling iron, or when changing to a different hair style.

CERAMIC

Your ceramic curling iron has many added benefits. The ceramic barrel technology provides increased heat distribution, eliminating the damaging hot spots found with other irons. When introduced to heat, ceramic is known to emit ion reflectives. Assisting in the breakdown of bacteria build-up, the reflectives enhance and renew the vitality of your hair. This ceramic iron will give your hair a smooth, silky shine while eliminating frizz.

WARNING:

The barrel will get very hot within a few seconds and should not be placed in contact with the skin after the curling iron is plugged in. The special heating system of this appliance will result in an extremely hot barrel when a high setting is chosen. Always do a test curl before using the appliance to ensure the proper setting for your hair type.

If in doubt start at a low temperature setting and adjust upwards until the desired results are achieved.

NOTICE

THIS PRODUCT IS EQUIPPED WITH AN INSTANT HEAT CIRCUITRY.

DO NOT LEAVE PRODUCT ON OR PLUGGED IN WHILE NOT IN USE. UNIT WILL BURN OUT

IF POWER IS KEPT ON FOR AN EXTENDED PERIOD OF TIME. WARRANTY WILL BE VOIDED. TURN UNIT OFF AND UNPLUG WHEN NOT IN USE.

USER MAINTENANCE

Your iron is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow it to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the unit. Damage will occur at the high flex point of entry into the unit, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently

STORAGE

When not in use, your appliance is easy to store. Allow unit to cool, then simply put back in the box and store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

GET TO KNOW YOUR PROFESSIONAL CERAMIC CURLING IRON

Barrel Sizes: Ø25mm



TWO YEAR WARRANTY

The warranty may only be claimed where proof of original purchase is presented, i.e. original purchase receipt or invoice. We recommend attaching a copy of your purchase receipt to this instruction book and storing in a safe place.

To make a warranty claim you can return the defective product back to the place it was purchased where it will be replaced, exchanged or repaired (see point 12 in conditions).

Trade purchasers who have purchased from us directly should contact us directly with regard to warranty claims.

Please have the following details to hand:

1. Date of purchase
2. Details of where the product was purchased
3. Product Name/Model Number
4. Confirm you have your purchase receipt
5. Detail the problem with your product

It is important to retain your proof of purchase. We recommend attaching your receipt to this page.

For advice with regard to the warranty claim process please contact Customer Services:

Dateline Imports P/L
Professional Products Division
Banksmeadow, NSW 2019
Australia
Ph: 61 2 9666 3611
www.babyliisspro.com.au

Dateline Imports NZ Ltd
66 Apollo Drive
Albany, Auckland
NZ 0632
Ph: 64 9 415 5415
www.babyliisspro.co.nz

WARRANTY AGAINST DEFECTS

A. AUSTRALIAN CONSUMER LAW

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The guarantees under the Australian Consumer Law ("ACL") are provided in sections 51 to 59 inclusive of the ACL ("Statutory Guarantees") and the remedies are provided in sections 259 to 266 inclusive of the ACL ("Statutory Remedies").

In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

B. BabyliissPRO EXTENDED WARRANTY

1. In addition and subject to the Statutory Guarantees and Statutory Remedies, the following express warranty ("Warranty") commences from the date of purchase and continues for a period of 24 months ("Warranty Period") after which it expires. Subject to the conditions in Section C below, Dateline warrants to the original purchaser ("Purchaser") of the BabyliissPRO product that is the subject of this warranty ("Product") that if during the Warranty Period, the Product suffers from any defect caused by faults in materials or workmanship, Dateline will a) replace the Product, or b) exchange defective part in the Product or c) repair the Product, as Dateline may choose in its discretion ("Warranty"). In this Warranty "Dateline" means Dateline Imports P/L (ABN 60

000 557 282) of Banksmeadow, NSW 2019, Australia.

2. To honour the Warranty, Dateline must replace, or exchange parts in, or repair, the Product, as Dateline determines, in accordance with paragraph B1 above, subject always to the conditions in Section C below.
3. If any of the conditions in Section C below are inconsistent with any provisions of the ACL or regulations made there under, those provisions of the ACL or regulations shall prevail to the extent of the inconsistency.

C. CONDITIONS

1. The Product must be used in accordance with manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Product be attributable to misuse, abuse, accident, act of God such as lightning, or nonobservance of manufacturer's instructions on the part of the user. This Warranty does not cover ordinary wear and tear in the Product or its parts.
2. Dateline does not accept liability for a) any loss or damage however suffered, caused by or arising out of any failure to use the Product in accordance with the manufacturer's instructions, and b) any indirect, consequential or economic loss or damage however caused.
3. This Warranty is immediately void if – a) any serial number or appliance plate is removed or defaced, b) the Product has been serviced or otherwise repaired by a person not authorized to do so by Dateline or where non approved replacement parts are used.
4. The Product must be connected to the electrical voltage supply as specified in the ratings label located on the Product.

This Warranty does not cover defects arising from incorrect voltage supply.

5. This Warranty may only be claimed against where proof of original purchase is presented, for example, original receipt or invoice.
6. Any parts of the Product that need to be replaced, or if the whole Product needs to be replaced, the replaced Product, become the property of Dateline. The Warranty on any replacement Product or parts will expire on the same date that the Warranty Period on the original Product expires.
7. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Product which the Purchaser has under the ACL, and applicable laws in New Zealand, which rights and remedies by law may not be excluded. All other warranties and representations express and implied are hereby excluded.
8. The defect must have occurred during the Warranty Period and Purchaser bears the onus of proving that fact, and that the defect was not caused by any of the causes excluded from this Warranty.
9. This Warranty does not cover Products purchased from any person who is not a retailer serviced by Dateline Imports P/L or purchased second hand.
10. The Purchaser is responsible for all postage and freight charges and any other expenses incidental to claiming against this Warranty.
11. The Warranty excludes consumable items (such as blades or brushes) and normal wear and tear.
12. If you're certain your product is defective, and the product is covered by the terms of this warranty, you

need to take the product back to the place you purchased it from, where the retailer will replace the product for you, exchange defective parts, repair the Product or refund at Dateline's discretion. In this event, per the terms of this warranty you will need to present this portion of the warranty information and the purchase receipt as proof of purchase so please make sure you keep both these instructions and your receipt on hand for the duration of the warranty period.